



---

## INSTALLATION INSTRUCTIONS FOR SHOWER SEATS WITH SWING DOWN LEGS

(This style seat has adjustable height legs)

Recommended tools for installation:

- 1/4" Power Drill
- 1/8" drill bit when drilling through fiberglass
- (Use a 1/4" Carbide drill bit when drilling through ceramic tile)
- #2 Phillips Screw Driver and/or Phillips drill insert
- 1/2" Open end wrench or a small Crescent wrench
- Tape measure
- Pencil/pen
- Center Punch
- Silicone Caulk

These primary instructions are for installing the seat onto a CERAMIC TILED WALL. The tiled wall must be properly constructed so as to be rigid. In addition, the seat must be attached to studs (or attached in a method that provides similar strength). One method is to use wood reinforcements installed between the framing studs behind the wall board and tile to provide a solid mounting surface when fastening the seat to the wall.

(If your seat is without swing down legs, you will skip step 2. For step 1, you will still want to install the seat in the 17" to 19" height from the floor.)

- 1) Choose the height of the seat you want. Barrier Free style showers will typically have fold up seat installed at 17" to 19" height.
- 2) After selecting the height you desire, adjust each of the four legs to that height while maintaining the seat in a level position. Lock each of the lock nuts.
- 3) Place the seat against the wall of the shower where you want the seat to be located. Seat may be centered on the wall for a Barrier Free installation.
- 4) With the seat placed against the mounting wall, position the two hinges to the wall. Using a pencil, mark the holes in the flange onto the wall for each hinge. Remove seat from wall.

Note: When installing the seat onto a Ceramic Tiled wall, prior to drilling the mounting holes for each flange that you previously marked, use a center punch and lightly chip a small hole in the center of each of the three hole locations. (For drilling holes through tile, you require a 1/4" Carbide tipped drill bit). Only drill through the tile and base materials.

**DO NOT DRILL THROUGH THE BACKING.**

- 5) Using a power drill with a 1/4" diameter Carbide bit, drill through the wall tile the mounting holes for each flange.
- 6) Apply silicone caulking around and inside each drilled hole before installing the seat.
- 7) Place the seat against the mounting wall with each hinge aligned to the mounting holes. Utilizing Stainless Steel screws, place a Phillips screw driver into your power drill and securely tighten each of the screws.